SONY
make.believe

LCS-CS1

Protect your Cyber-shot® camera and accessories from dust and scratches with this soft carrying case.

Bullets

- Soft carying case with belt loop
- Velcro closure
- Zippered pocket for memory card and extra battery
- Available in black with blue trim

Features

Protect

Soft carrying case to protect your Cyber-Shot® camera

Flexible

Hand carry or attach to belt

Extra Pocket

Extra pocket for memory card and extra battery

Color options

Available in black with blue trim

Specifications

Dimensions (Approx.)	
Dimensions (Approx.)	3 1/4 x 5 1/8 x 1 3/8in (80 x 128 x 34mm)
Weights and Measurements	
Weight (Approx.)	1.7 oz (47g)
General	
Case Type	2 way (hand/belt)
Function	Organizer for camera and accessories: battery, memory card, etc
Material	Nylon/Polyester
Type of Use	Hand carry or belt loop

SONY
make.believe

© 2012 Sony Electronics Inc.
All rights reserved. Reproduction in whole or in part without written permission is prohibited.
All other trademarks are property of their respective owners.
Features and specifications are subject to change without notice. Non-metric weights and measures are approximate. /Updated: February 2, 2012